LUXURY VINYL PLANKS

Installation Guide

Proper installation of our products is needed to ensure long lasting reliability and durability. Ensure to use our floor coverings for indoors only.

Luxury Vinyl planks are strong and water resistant but water-based glues will wither on water. Thus ensure that our vinyl planks are used only on the following areas:

Approved locations



- Bedroom
- Living Room
- Dining Room
- Dry kitchen
- Commercial areas (non-high traffic)



Unapproved locations

- Wet kitchen
- Comfort room/washroom
- Balcony
- Outdoor areas
- High traffic public areas



- Luxury Vinyl Planks
- **Water Based Adhesive**
- 10/20mm self leveling mortat (optional)
- **Concrete Substrate**

WARNING: Do not use Rugby or any solvent-based adhesives as it will damage the vinyl planks.

Steps on how to install Vinyl planks:

- 1) The floor should be even and nearly flat. It should also be clean and clear of any debris to ensure a proper finish.
- 2) Prepare the vinyl planks and water-based glue. Use a trowel, paint roller or brush to distribute the right amount of glue on the floor surface and on the vinyl itself if needed.
- 3) Use our recommended water-based glue if available. Our Big Ass Bond adhesive is designed and blended specifically for our luxury vinyl planks.









Chevron

LUXURY VINYL PLANKS







- 5) Prevent from stepping or walking over the planks after installation. To ensure the strength of the glue, let it fully cure for about 24 42 hours.
- 6) After the glue has fully cured, sweep the floor, and use a damp cloth or mop to clean the vinyl flooring for a clean and desirable finish.
- 7) For care and maintenance, only use damp cloth or a clean damp mop. Never use wax or any bleach products as it may damage the vinyl planks.



We recommend using our **Big Ass Bond** adhesive for our Luxury Vinyl planks as its mixture is optimized specifically for our planks.

Available in 1 kilo and 1 gallon Concentrated mixture, less is more.



